

# Product data sheet


**KitchenAid**



<b>Control panel</b>	<b>4</b>
<b>Warming drawer</b>	<b>4</b>
<b>Operation</b>	<b>4</b>
<b>Temperature selection</b>	<b>5</b>
<b>Warming times</b>	<b>5</b>
<b>Load capacity</b>	<b>6</b>
<b>Drawer removal</b>	<b>7</b>

## Control panel

1. Temperature knob
2. Luminous ON-OFF switch
3. ON-OFF Indicator



## Warming drawer

The control elements are the temperature knob and the luminous **ON-OFF switch**.

With the switch pressed (position **1**), the drawer is on, whereas with the switch released (position **0**), the drawer is off.

These elements are only visible when the drawer is open.

When the drawer is closed, a control light located on the front of the appliance indicates if the drawer is on.

## Operation

- Place the dishes in the drawer
- Set a temperature
- Turn the appliance on; the switch lights up
- Close the drawer, guiding it carefully
- Turn the appliance off before removing the warmed dishes.

## Temperature selection

The temperature control knob allows adjustments up to approx. 75°C (max).

Turn the temperature knob clockwise until the stop which indicates maximum, and then anticlockwise.

Do not force it beyond the stop, otherwise the thermostat will become damaged.

Temperature adjustment	Instructions for use	
40°C	cups, glasses	Cups and glasses warmed at this temperature help delay the cooling time of the beverage subsequently added. The container can still be touched without any problems
60°C	plates	Plates warmed at this temperature help delay the cooling time of food subsequently placed on them. Depending on the individual sensitivity, the containers can be touched without any risk, otherwise use gloves or potholders.
MAX (approx. 75°C)	crockery	The thermostat is set to the maximum temperature. The containers can be touched ONLY with suitable gloves or potholders.

## Warming times

The time required to warm dishes, glasses, etc. depends on various factors:

- Material and thickness of the dishes
- Load
- Arrangement of load
- Temperature setting

Therefore absolute indications cannot be given.

It is advisable to establish the optimum settings required, according to practical experience.

## Load capacity

The load capacity depends on the height of the appliance and the size of the dishes.

The following load examples are only a guide

Remember that the drawer can take a maximum weight of 25 kg.

Dishes for 6 persons

<b>6</b>	<b>plates</b>	<b>ø 28cm</b>
<b>6</b>	<b>broth cups</b>	<b>ø 10cm</b>
<b>1</b>	<b>soup plate</b>	<b>ø 22cm</b>
<b>1</b>	<b>soup plate</b>	<b>ø 19cm</b>
<b>1</b>	<b>soup plate</b>	<b>ø 17cm</b>
<b>2</b>	<b>meat plates</b>	<b>ø 36cm</b>

or as required

<b>20</b>	<b>plates</b>	<b>ø 26cm</b>
<b>36</b>	<b>soup plates</b>	<b>ø 22cm</b>
<b>30</b>	<b>soup plates</b>	<b>ø 10cm</b>
<b>10</b>	<b>plates</b>	<b>ø 27cm</b>
<b>10</b>	<b>soup plates</b>	<b>ø 22cm</b>
<b>10</b>	<b>pizza plates</b>	<b>ø 36cm</b>
<b>80</b>	<b>espresso coffee cups</b>	
<b>40</b>	<b>cappuccino cups</b>	
<b>30</b>	<b>glasses (grog)</b>	
<b>18</b>	<b>soup plates</b>	<b>ø 22cm</b>
<b>2</b>	<b>meat plates</b>	<b>21 x 18 cm</b>

## Drawer removal

### **⚠ ATTENTION:**

- Use protective gloves
- Disconnect the appliance from the power supply.

The drawer can be removed to clean it internally.  
Open the drawer completely (**figure 1**).

Undo the four side screws (two on each side)  
(**figure 2**).

Pull out the sliding part of the drawer carefully,  
holding it at the front and side with both hands  
(**figure 3**).

The appliance can now be cleaned internally, using  
detergent and water.

Do not place the drawer in water once removed.

### **Refitting the drawer**

To refit the drawer, carry out the removal procedure  
in reverse order.

To do this, place the drawer on the runners.

Make sure to:


Insert the drawer with the runners completely out.  
Hold the runners with one hand and push the  
drawer until alignment of the 4 side holes  
(**figures 4-5**).




**Figure 1**




**Figure 2**



**Figure 3**



**Figure 4**



**Figure 5**



FOR THE WAY IT'S MADE.

Printed in Italy  
05/15

400010794638

