

- To use the hob turn the knob(s) clockwise and position at the required power setting.
- To switch off the hob return the knob(s) to position "0".
- The hob is provided with 2 indicator lights showing when the cooking zones are hot. These indicator lights switch on as soon as the cooking zones reach a high temperature. These indicator lights remain on even after switching off the relevant cooking zone and they switch off only when the temperature of the cooking zone is no longer dangerous.

- Radiating cooking zone Ø 145
- Radiating cooking zone Ø 180
- Control knob for rear cooking zone ■
- Control knob for front cooking zone ■
- Residual heat indicator

Important:
To avoid permanently damaging the glass ceramic top, do not use:


- pots with bottoms that are not perfectly flat,
- metal pots with enamelled bottom.

ELECTRICAL CONNECTION

Power supply voltage	Number of wires x dimensions
220-240 + ⊕	H05 RR-F 3 X 1.5 mm ²

DIMENSIONS OF COOKING HOB AND WORKTOP (MM)

Power supply voltage	Number of wires x dimensions	Knob (1-12)
1-2	Melting butter, chocolate, etc.	1-2
2	Keeping food warm and reheating small quantities of liquid	2-3-4
3	Heating larger quantities, making custards and sauces	4-5-6
3-4	Gentle simmering, for example: boiled vegetables, spaghetti, soups, pot roasts, stews	6-7
4	For all fried food, cutlets, steaks, cooking without use of lid, for example: risotto	7-8
4-5	Browning meats, roast potatoes, fried fish and to boil large quantities of water	8-9-10
6	Brisk frying, griddling steaks, etc.	11-12



These instructions shall also be available on website:
 docs.whirlpool.eu

IMPORTANT SAFETY INSTRUCTIONS

YOUR SAFETY AND THAT OF OTHERS IS VERY IMPORTANT

This manual and the appliance itself provide important safety messages, to be read and observed at all times.

WARNING:

All messages relevant to safety specify the potential risk to which they refer and indicate how to reduce the risk of injury, damage and electric shocks due to incorrect use of the appliance. Make sure to comply with the following:

- The appliance must be disconnected from the power supply before carrying out any installation operation.
- Installation and maintenance must be carried out by a specialised technician, in compliance with the manufacturer's instructions and the local safety regulations in force. Do not repair or replace any part of the appliance unless specifically stated in the user manual.
- The appliance must be earthed.
- The power cable must be long enough for connecting the appliance, fitted in the cabinet, to the power supply.
- For installation to comply with the current safety regulations, an omnipolar switch with minimum contact gap of 3 mm is required.
- Do not use multi-sockets or extension cords.
- Do not pull the appliance's power cable.
- The electrical parts must not be accessible to the user after installation.
- The appliance is designed solely for domestic use for cooking food. No other use is permitted (e.g. heating rooms). The Manufacturer declines any liability for inappropriate use or incorrect setting of the controls.
- The appliance and its accessible parts become hot during use. Care should be taken to avoid touching heating elements. Children less than 8 years old shall be kept away unless continuously supervised.
- The accessible parts can become very hot

during use. Children must be kept away from the appliance and watched over to ensure they do not play with it.

- Do not touch the appliance heating elements during and after use. Do not allow the appliance to come into contact with cloths or other flammable materials until all the components have cooled sufficiently.
- Do not place flammable materials on or near the appliance.
- Overheated oils and fats catch fire easily. Pay attention when cooking food products rich in fat and oil.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand hazards involved. Cleaning and user maintenance shall not be made by children without supervision.
- If the surface is cracked, switch off the appliance to avoid the possibility of electric shock.
- The appliance is not intended to be operated by means of an external timer or separate remote control system.
- Unattended cooking on a hob with fat or oil can be dangerous and may result in fire. NEVER try to extinguish a fire with water, but switch off the appliance and then cover flame e.g. with a lid or a fire blanket.
- Danger of fire: do not store items on the cooking surfaces.
- Do not use steam cleaners.
- Metallic objects such as knives, forks, spoons and lids should not be placed on the hob surface since they can get hot.

TYPE PLEVP 220-240/380-415V~2N/50/60 Hz 2.9 KW



BEFORE USING THE COOKING HOB

Before use, remove:

- adhesives stuck on the hob;
- cardboard guards and protective plastic film;
- check whether the hob has been damaged during transport. If in doubt, contact the After Sales Service

CARE AND MAINTENANCE

Important: never clean the appliance with high pressure water or steam cleaning equipment.

- Clean with warm water and/or neutral detergents. Rinse and dry the hob surface carefully with a soft or leather cloth.
- The stainless steel surface may become stained or corroded when prolonged exposure to abrasive pads, detergents containing chlorine (or its compounds), ammonia or high acidic substances. Prior to first use, consult the cleaning product label to access full suitability.
- Avoid prolonged contact with acid and alkaline substances, such as vinegar, mustard, salt sugar or lemon juice.
- Any food spills, such as water, sauce, coffee, should be promptly wiped dry.
- Do not use abrasive cleaners or scouring pads.
- Do not use steam cleaners
- Do not use flammable products
- The enamelled and glass parts should be cleaned with warm water and/or a neutral detergent.

TROUBLESHOOTING GUIDE

The hob does not work:

- Check for the presence of mains electrical power.
- Switch the hob off and then back on again, to see if the problem has been solved.
- Make sure that the knob is not turned to "0". Turn the multi-pole switch to "Off" for a few minutes and then turn it back to "On".

AFTER SALES SERVICE

Before contacting After-Sales Service:

- Make sure that you cannot solve the problem yourself following the points described in chapter "Troubleshooting Guide".

If after the above checks the fault persists, contact the nearest After Sales Service.

Please give:

- a brief description of the fault;
- the type and exact model of the hob;
- the service number (i.e., the number that follows the word SERVICE on the rating plate, located under the hob). The service number is also indicated on the warranty booklet;
- your full address;
- your telephone number and area code.

If any repairs are required, please contact an authorised **After Sales Service** (to guarantee that original spare parts will be used and repairs carried out correctly).

Failure to comply with these instructions may compromise the safety and quality of the product.

INSTALLATION

Recommendations

Important: Disconnect the hob from the mains before carrying out any installation work or servicing.

- All electrical connections must be made before connecting the appliance to the power supply.
- Installation must be carried out by a qualified technician in accordance with the manufacturer's instructions and in compliance with local regulations.
- Unpack the hob and make sure that the appliance has not been damaged during transport. **If you are not sure contact the dealer or the nearest service centre.**

Preparing the housing unit

- Cut the worktop to fit before installing the appliance. Carefully remove any shavings or sawdust that could prevent the appliance from running properly.
- The hob must be fitted in a worktop with a minimum thickness of 30 mm and a maximum of 50 mm.
- Insert a separator at least 20 mm from the lower edge of the hob, so that it cannot be accessed by the user.

- If there is an oven under the hob, make sure that it is manufactured by Whirlpool and equipped with a cooling system.
- There must be nothing between the hob and the oven (e.g. cables, insulating material, etc.).
- An adjacent column unit must be installed at least 100 mm from the edge of the hob.
- Cut an opening in the worktop of the given dimensions.
- We recommend you seal the internal edges of the worktop with wood glue or silicone.
- If not already in place, apply the supplied seal to the hob, after cleaning the adhesive surface thoroughly.

Glass ceramic hob

Important: remove any protective film before installing the hob.


Make sure that the opening in the worktop for the hob is cut according to the dimensions given in the drawing, paying attention to the tolerance range.

Connecting the hob to the power supply

Note: the yellow/green earth wire must be connected to the screw marked ⚡.

If the supply cable is not already connected:

- Strip away approximately 70 mm. of the outer sheath of the cable.
- Then strip away approximately 10 mm. of the inner sheath.



- Open the terminal board by pushing the side clips in with the help of a tool.
- Insert the cable in the cable clamp and connect the wires to the terminal board.
- Close the cover of the terminal board.
- After the electrical connection, fit the hob from the top and hook it to the fixing springs, as shown in fig. 1

Eco Design Declaration

This appliance meets the eco design requirements of European regulation N. 66/2014, in conformity to the European standard EN 60350-2.

PROTECTING THE ENVIRONMENT

Disposal of packaging materials:

- The packing material can all be fully recycled, as confirmed by the recycling symbol ♻️.
- Do not dispose of the various packaging materials carelessly, but do so responsibly and in full compliance with local authority regulations governing waste disposal.

Disposal of used household appliances.

- This appliance is marked according to the European directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE). By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. The symbol  on the product, or on the documents accompanying the product, indicates that this appliance may not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. Disposal must be carried out in accordance with local environmental regulations for waste disposal. For more detailed information about treatment, recovery and recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product

Energy saving tips.

- Use pots and pans whose bottom diameter is equal to, or slightly larger than, that of the cooking zones.
- Only use flat-bottomed pots and pans.
- If possible, keep pot lids on when cooking.
- Cook vegetables, potatoes, etc. with little water in order to cut down cooking time.
- A pressure cooker allows you to save even more energy and time.

