

# KitchenAid®

## CITRUSPERS

GIDS VOOR HET BESTE RESULTAAT

## CITRUS JUICER

GUIDE TO EXPERT RESULT

## PRESSE-AGRUMES

GUIDE DU CONNAISSEUR

## ZITRUSPRESSE

ANLEITUNG FÜR PROFI-ERGBNISSE

## SPREMIAGRUMI

GUIDA PER OTTENERE RISULTATI PROFESSIONALI

## EXPRIMIDOR

GUÍA PARA CONSEGUIR RESULTADOS PROFESIONALES

## CITRUSPRESS

GUIDE FÖR EXPERTRESULTAT

## SITRUSPRESSE

VEILEDNING FOR PROFESJONELLE RESULTATER

## SITRUSPUSERRIN

OPAS PARHAISIIN TULOSSIIN

## CITRUSPRESSER

SÅDAN FÅR DU DE BEDSTE RESULTATER

## ESPREMEDOR DE CITRINOS

GUÍA PARA RESULTADOS PROFISSIONAIS

## SÍTRUSPRESSA

LEIÐBEININGARUM RÉTTA NOTKUN

## ΛΕΜΟΝΟΣΤΙΦΤΗΣ

ΟΔΗΓΟΣ ΓΙΑ ΕΠΑΓΓΕΛΜΑΤΙΚΑ ΑΠΟΤΕΛΕΣΜΑΤΑ



Model 5JE

Citrus Juicer

Designed exclusively for use with all  
KitchenAid® Household Stand Mixers.

# Table of Contents

Important Safeguards .....	3
Citrus Juicer Attachment.....	4
Assembling Your Citrus Juicer .....	4
Using Your Citrus Juicer .....	5
Care and Cleaning .....	5
Household KitchenAid® Stand Mixer Attachment Warranty.....	6
Service Centers.....	6
Customer Service .....	6

## Your safety and the safety of others are very important.

We have provided many important safety messages in this manual and on your appliance. Always read and obey all safety messages.



This is the safety alert symbol.

This symbol alerts you to potential hazards that can kill or hurt you and others.

All safety messages will follow the safety alert symbol and either the word "DANGER" or "WARNING." These words mean:

** DANGER**

**You can be killed or seriously injured if you don't immediately follow instructions.**

** WARNING**

**You can be killed or seriously injured if you don't follow instructions.**

All safety messages will tell you what the potential hazard is, tell you how to reduce the chance of injury, and tell you what can happen if the instructions are not followed.

# IMPORTANT SAFEGUARDS

---

When using electrical appliances, basic safety precautions should always be followed including the following:

1. Read all instructions.
2. To protect against risk of electrical shock, do not put mixer in water or other liquid.
3. The appliance is not intended for use by young children or infirm persons without supervision.
4. Unplug mixer from outlet when not in use, before putting on or taking off parts and before cleaning.
5. Avoid contacting moving parts. Keep fingers out of discharge opening.
6. Do not operate the mixer with a damaged cord or plug or after the mixer malfunctions, or is dropped or damaged in any manner. Return the mixer to the nearest Authorized Service Center for examination, repair or electrical or mechanical adjustment.
7. The use of attachments not recommended or sold by KitchenAid may cause fire, electric shock or injury.
8. Do not use the mixer outdoors.
9. Do not let the cord hang over the edge of table or counter.
10. Do not let cord contact hot surface, including the stove.
11. Check hopper for presence of foreign objects before using.
12. This product is designed for household use only.

## SAVE THESE INSTRUCTIONS


# Citrus Juicer Attachment

**Shield (A)** – deflects juice overspray and directs juice into container below

**Strainer (C)** — collects citrus pulp and separates it from juice

**Reamer (B)** — rotates to extract juice from citrus fruit

**Power Shaft (D)** — transfers drive power from mixer to reamer



## Assembling Your Citrus Juicer


### To Assemble:

Insert round end of metal shaft (D) into reamer (B) so pins fit into slot. Insert square end of shaft through shaft housing portion of shield (A). Place strainer (C), narrow end first, into slots in shield.

### To Attach:

Before attaching accessory, turn off and unplug the stand mixer.

1. Depending on which type of hub you have, either flip up the hinged cover or loosen the attachment knob (E) by turning it counterclockwise. Remove, or flip up, attachment hub cover.
2. Insert the attachment shaft housing (F) into attachment hub (G) making certain that the attachment power shaft fits into square hub socket. Rotate attachment back and forth if necessary. When the attachment is in proper position, the pin on the attachment will fit into the notch on the hub rim.
3. Tighten the attachment knob (E) until the unit is completely secured to the mixer.



# Using Your Citrus Juicer

---

## To Use:

Citrus Juicer is designed to juice lemons, limes, oranges, and grapefruit. Place glass or pitcher under Citrus Juicer to catch juice. Turn to Speed 6. Holding fruit firmly cupped in hand, bring fruit in contact with spinning reamer. Move fruit in all directions, exerting inward and downward pressure to extract the juice. Clean strainer as often as necessary.



## Care and Cleaning

---

### To Clean:

Wash in warm sudsy water. If you wish you may place components on the top rack of your dishwasher. However, we recommend that you wash the aluminum shaft in warm sudsy water.

# Household KitchenAid® Stand Mixer Attachment Warranty

Length of Warranty:	KitchenAid Will Pay For :	KitchenAid Will Not Pay For :
<p><b>Europe &amp; Australia:</b> Two Year Full Warranty from date of purchase.</p> <p><b>Other:</b> One Year Full Warranty from date of purchase.</p>	<p>Replacement parts and repair labor costs to correct defects in materials or workmanship. Service must be provided by an Authorized KitchenAid Service Center.</p>	<p>A. Repairs when Citrus Juicer is used for operations other than normal household food preparation</p> <p>B. Damage resulting from accident, alterations, misuse, abuse, or installation/operation not in accordance with local electrical codes.</p>

English

**KITCHENAID DOES NOT ASSUME ANY RESPONSIBILITY FOR INDIRECT DAMAGES.**

## Service Centers

All service should be handled locally by an Authorized KitchenAid Service Center. Contact the dealer from whom the unit was purchased to obtain the name of the nearest Authorized KitchenAid Service Center.

**In the U.K.:**  
Call: 0845 6011 287

**In Ireland:**  
M.X. ELECTRIC  
Service Department  
25 Alymer Crescent  
Kilcock, CO.KILDARE  
Call: 1 679 2398/87 2581574  
Fax: 1 628 4368

**In Australia:**  
Call: 1800 990 990

**In New Zealand:**  
Call: 0800 881 200

## Customer Service

**In U.K. & Ireland:** Tollfree number 00800 38104026

**Address:** KitchenAid Europa, Inc.  
PO BOX 19  
B-2018 ANTWERP 11  
BELGIUM

[www.KitchenAid.com](http://www.KitchenAid.com)



**FOR THE WAY IT'S MADE.™**

® Registered Trademark of KitchenAid, U.S.A.

™ Trademark of KitchenAid, U.S.A.

The shape of the stand mixer is a trademark of KitchenAid, U.S.A.

© 2006. All rights reserved.

Specifications subject to change without notice.